
# Electric Dropbolt Installation Instructions (Fail-Secure Series)

### **Specifications**


EB270 EB270M (Monitored)


Operating Voltage		12~28VDC
Voltage Tolerance		±10%
Current Draw		1.2A/12VDC
Operating Temperature		-10~+45°C
Humidity		0~95%
Auto Relocking Timer Setting (Default setting)		5 Seconds
Dimensions	Lock	260x30x48mm
	Strike Plate	100x46x1.5mm

Fail-Secure series of Electric Dropbolt Locks are not suitable for double action swing doors. They are only suitable for either inswing or outswing doors.





Reverse the latchbolt for right or left handed doors.






Unit:mm





Drill holes and mortise door edge according to the template







Connect wiring to the lock

Insert the lock into mortise cutout and fasten screws to doors

## Wiring Diagram




### Butt Splice (IDC) Connector



Attach fixing lugs

#### Cut hole in the door for cylinder



#### Warning

- 1. The connection of an incorrect voltage may result in damage and is not covered by the product warranty.
- 2. Select the appropriate power supply cable to ensure if the lock receives sufficient power to operate.
- This product has been designed for use in weather protected areas and normal circumstances, hence it does not require any maintenance. DO NOT OIL OR LUBRICATE.
- 4. This product must be used in conjunction with a quality floor spring or door closer to ensure positive realignment on closing.

Place the wire inside the connector and use pliers to press down on the head of the connector evenly.