MOD-AD500DB Interlock Module Installation Instructions

AD500DB Module

AD500DB Module

Jumper Setting

Jumper Setting

Master

Slave

(Cable length: 2.5 meters)

22AWGx4C

22AWGx4C

AD500DB Module

AD500DB Module

Instructions:

Install the AD500DB Interlock Module on the AD500 Control Unit per shown in the diagram. Configure 'Master' and 'Slave' through jumper setting for the system to reconise the order in which the doors will open.

1. Master door opens first

2. Once master door opens, slave door follows.

3. Slave door closes first

4. slave door is closed, master door will start to close.